

开头语

感谢您购买500系列绷缝机，我们表示衷心的感谢！

您！

您！

您！



在平时，除了对机器进行日常保养之外，也请您多加注意自身的安全，做到安全使用。这是我们的心愿。

使用说明
零件样本

OPERATION MANUAL
PARTS BOOK

BML-500 Series
高速绷缝机系列

High Speed
Interlock Sewing Machine

Scan by zhuravli.pro

浙江宝宇缝纫机股份有限公司
ZHEJIANG BAOYU SEWING MACHINE CO.,LTD.

开头语

为您购买 500 系列绷缝机，我们表示衷心的感谢！

在使用缝纫机之前，请认真阅读此说明书。愿您自始至终爱护并使用本公司的产品。

另外，为使您的缝纫机高效率的使用，此说明书登载了有关日常中检查与安全的注意事项，

在平时，除了对绷缝机进行检查之外，也请您多加注意自身的安全，做到安全使用。这是我们的心愿。




为了安全

对于缝纫机本身及各种装置，我们充分考虑到它的安全性。请遵照基本的操作方法，安全的进行工作。

●拆除为保证安全所设置的装置，零件的情况下使用，是非常危险的，请绝对不要拆除后使用。

●缝纫机在使用时，请不要在缝纫机台板上放置工具及缝纫机时不必要的物品。

●在对缝纫机进行检修、调节、清扫、穿线、换针等时，为防止发生事故，务必请切断电源，在确定即使踩缝纫机踏板，缝纫机也不转动之后，再进行操作。




● 在离开缝纫机台时，务必请关掉电源。

● 停电时也请务必关掉电源。

注意

使用离合式马达的情况下，在关掉电源①后因惯性作用会继续旋转。这时如不注意踩动缝纫机踏板②时，缝纫机会突然动作，这是很危险的。

请在关掉电源后，仍继续踩动踏板②，直至缝纫机完全停下来为止。



● 为了总是安全地，运转良好的使用缝纫机，日常的点检是不可缺少的，请予以注意。

INTRODUCTION

Thank you very much for purchasing 500 Series machine.

This instruction manual describes daily routine maintenance and safety precautions to keep the machine in the best possible conditions.

Please study this manual very carefully before operating the machine.



CAUTION

OBSERVE THESE SAFETY PRECAUTIONS



Though Sewing Machine takes the utmost care to produce safe sewing machines and devices, operators should follow these basic safety rules.

- To prevent accidents, do not remove safety devices or parts while operating the machine.
- Do not leave tools or other unnecessary objects on the machine table while operating the machine.
- Before maintenance, adjusting, cleaning, threading or replacing the needle, and to

prevent accidents, be sure the power is turned off. Check that the machine will not operate when the pedal is pressed.

Note

In case a clutch type motor is used, it will keep on rotating by inertia after turning off power supply ①. If the machine pedal ② is stepped on inadvertently, it is dangerous because the machine will move unexpectedly. Keep on stepping on the pedal ② until the machine comes to a stop after turning off power supply.



- Turn the power off before leaving the machine table.
- In the event of a power failure, be sure to turn the machine off.
- Check that the machine is securely grounded.

目 录

■ 在使用之前	页码
○ 供油	1
○ 手动给油	2
○ 给H R装置供油	3
○ 穿线的方法	4
○ 穿线图 (2针、3针、4针用)	5
■ 试缝	
○ 压脚压力的调节	6
○ 差动比的调节	7
○ 针脚长度的调节	8
○ 线状态的调节	9
■ 使用中的保养	
○ 缝纫机的清扫	10
○ 换针	11
○ 检查机油的循环	12
○ 机油过滤器的检点与更换	13
○ 换机油	14
○ 调整标准参数表	15
○ 标准度量零件表	16-28

CONTENS


■ BEFORE OPERATING	PAGE
○ Lubrication	1
○ Manual lubrication	2
○ Filling the HR device with silicon oil	3
○ Threading	4
○ Threading diagram (2-needle/3-needle/4-needle)	5
 ■ TEST SEWING	
○ Presser foot pressure	6
○ Diff.feed ratio	7
○ Stitch length	8
○ Thread tention	9
 ■ MAINTENANCE DURING USE	
○ Cleaning the maching	10
○ Replacing the needle	11
○ Checking the oil circulation	12
○ Checking and replaceing the oil filter	13
○ Replaceing the oil	14
○ Adjustment Dimensions	15
○ Adjustment Dimensions	16-28

在使用之前
BEFORE
OPERATING

供 油 Lubrication

加油量是使油面于H线与L线之间为好。当油量低于L线时，就要及时补充机油。

After filling the oil pan, the oil surface should lie between (H) and (L) lines. Add oil, when the oil surface reaches or goes below (L).




在使用之前
BEFORE
OPERATING

手动给油 Manual lubrication

手动给油是在缝纫机最初开始使用时，或相当一段时间没使用了时，请供给2~3滴油。

Apply 2 or 3 drops of oil by hand when the machine is used for the first time or has been left unused for some time.



在使用之前
BEFORE
OPERATING


给HR装置供油 Filling the HR device with silicon oil

为了防止布纤维或线被切断，请
尽早给HR装置供油。

Fill the device with oil before it is too low in order
to prevent needle thread breakage and fabric
damage.

注：关于购买硅酯油，请问缝纫机
代销店或与公司营业所联系。


Note: Use recommended silicon oil.
(UNION CARBIDE CORPORATION)
UCCL-45(350)




在使用之前
BEFORE
OPERATING

穿线的方法 Threading

- ① 请掀起护眼板，打开机盖（3处）。
Open the eye guard and three covers.




- ② 提起。
Press down.




弯针挑线器提到上面。
The looper thread take-up comes out.

- ④ 穿好线后将弯针挑线器压回原位。
Replace the looper thread take-up after threading.



把机上原有的线与缝纫用线
绑结在一起。
Knot the preset thread and the
thread being used together to
thread the machine.




针线

将线拉到针跟前。剪掉
结头再次穿好针线。


Needle thread

Trim the knots off neatly
before passing through
the eye of the needle to
thread.



若机上原来没有线，请参照穿
线图正确进行穿线。

Be sure to thread the ma-
chine correctly by referring to
the threading diagram. (See P.
5)



穿针线、上饰线
直到拉出接头来后，用剪刀
剪掉接头，整齐。

**Looper thread, Top
cover thread**



Trim the knots off neatly
after passing through
the eye of the looper

在使用之前
BEFORE
OPERATING

穿线图(2针、3针、4针) Threading diagram (2.3.-needle)



Solid lines
for ordinary thread




在使用之前
BEFORE
OPERATING

压脚压力的调节 Presser foot pressure

压脚压力的调节是松开螺帽①和旋转螺丝②来进行的。在能取得平稳针脚的范围内，尽量调得松一些为好。

Loosen adjusting (1) nut and turn adjusting screw (2) to adjust the presser foot pressure. It should be as light as possible, yet be sufficient to obtain the proper stitch formation.




试 缝
TEST SEWING

差动比的调节

Diff. feed ratio adjustment

差动比是通过松开螺帽①后，把调节杆②上下移动来进行调节的，调节后请拧紧螺帽①。

Loosen nut (1) and move the lever up (2) and down to obtain the correct differential feed ratio. then tighten nut (1).



试 缝
TEST SEWING



针脚长度的调节 Stitch length adjustment

- ① 摁住针距调节按钮，旋转手轮，针距调节按钮会陷进更深处。
- ② 这时边摁住针距调节按钮，边转动手轮，使校准标记对准所希望的数值。

注：针脚长度的调节务必请在调节差动比之后进行。

While pressing the push button, turn the handwheel to seek the position at which the push button goes further into the depth. Then, keeping the push button pressed, turn the handwheel and set the desired scale to the aligning mark.

Note: Stitch length adjustment must only be made after the differential feed ratio has been changed.




试 缝 TEST SEWING

线状态的调节 Thread tension

线张力状态的调节，请用针线状态螺帽①、上弯针状态螺帽②、弯针线状态调节螺帽③来进行调节。

Mack tension adjustments with the needle thread knob (1), top cover thread knob (2), and looper thread knob (3).



使用中的保养
MAINTENANCE
DURING USE

缝纫机的清扫 Cleaning the machine


缝纫机的清扫，以针板槽及送布牙周围为主。

Mainly the slots of the needle plate and the feed rows should be cleaned.

注：升降长压脚的调节螺丝在更换线迹之后进行。

While pressing the
handwheel to seek the position at which the push
button goes up, the
Then, keep the push button in the
handwheel at the position
aligning mark.

Note: Adjust the
after the
changed.



使用中的保养
MAINTENANCE
DURING USE




换 针

Replacing the needle



准确辨认针的前后，请将针凹向着后方，即背向操作者进行安装。
针要牢固的插到孔的最里头。


- *Check the needle carefully to see that the scarf is turned to the rear of the machine.
- *Insert the needle to the proper depth, and fasten securely.



针 凹 部 分
Scarf

标准用针
Standard needle

		针的尺寸 NEEDLE SIZE	
		2 针 2-needle	3 针 3-needle
风琴牌 Organ	UY128GAS	# 9	# 10
蓝狮牌 Schmetz	UY128GAS		




【注意】请不要把螺丝卸下来。
【Note】Do not remove the screw.

请使用附属品的螺丝板
Be sure to use the allen key wrench packaged in the accessory box.

使用中的保养
MAINTENANCE
DURING USE

检查机油的循环 Checking the oil circulation




使用中的保养
MAINTENANCE
DURING USE

油过滤器的检点与更换 Checking and replacing the oil filter

机油过滤器，请于每6个月拆下来检点或更换一次。

Check and replace the oil filter every six months.



检点和更换每隔6个月进行一次!
CHECK AND REPLACE
EVERY 6 MONTHS!A

注：缝纫机附带有UT装置时，请拆下螺线管托架。

NOTE: On machines fit with a UT Device, remove the solenoid bracket.


使用中的保养
MAINTENANCE
DURING USE

换 机 油
Replacing the oil

机油的更换，请在使用开始1个月后更换一次。
然后，每6个月更换一次。

Replace the oil one month after the first use
and every six months thereafter.

供油请参见第1页 (See P.1)



500 调整标准参数表

500 Adjustment Dimensions (mm)

500-01CB	224	10.2	4.8~5.1	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
02BB	232	9.8	4.4~4.7	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
03EB	248	8.9	3.6~3.9	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
04DB	256	8.5	3.2~3.5	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
05MD	264	8.1	2.8~3.1	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
06HD	348	9.4	3.6~3.9	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
07FD	356	8.5	8.3~8.7	8.3~8.7	4.5~5.0	17.0	0.8~1.2			
08AB	364	8.1	2.8~3.1	8.3~8.7	4.5~5.0	17.0	0.8~1.2			

针号对照表

标准用针


Japanese size (Organ)	#	9	10	11	14	16	18	21
Metric size (Schmetz)	Nm	65	70	75	90	100	110	130

500-01CB	x □ □ □	Organ UY128GAS
02BB		
02EB	224	9S
04DB	232	9S
05MD	248	9S
	256	9S
06HD	264	9S
07FD	348	10S
	356	10S
08AB	364	10S

5

上轴部份


Main shaft assemblies



6

针杆部份


Needle bar assemblies



7

护针部份


Needle guard assemblies



8

弯针部份

Looper assemblies




13 松线部份

● 2-Needle, Without top cover thread.

254023B9U

● 2-Needle, With top cover thread.

254023C9U




● 3-Needle, Without top cover thread.

254023D9U


● 3-Needle, With top cover thread.

254023E9U




14 过线部份

Thread guide assemblies




15 过线凸轮部份

Cam assemblies




16 润滑部份

Lubrication assemblies





21

● 01(Except-01D,01G),03,21
250030-PD
250032 - PD




● 06B,07B,08
01D
250032BPD




22

01D





254024 - 9U




23

● 02B



24



03




25

05
250532 - 91

05




05




26

05




05/FT140




27

05/FT140




28

06,07




258000 - 91




500-05,06,07

306469A9S



500 - 05,07


500-05 MD(OPTION)



500-05,07

500-05/MD (OPTION)

256064 - 9S




*=(not for sale.)

500-08


(Standard)

- For light weight fabric 257571
- For heavy weight fabric 257571 (Put in accessory)

● 500-08A



500-21




*=(not for sale.)


33

Please confirm the correct part by the gauge parts lists
500-21


CRANKSHAFT MECHANISM



ARM AHAFT MECHANISM



NEEDLE SPREADER
THREAD HANDLING




*(not for sale.)


34

500-21


LOOPER MECHANISM



FEED MECHANISM



LUBRICATION MECHANISM





*(not for sale.)


35

Please confirm the correct part by the gauge parts lists
500-84

250032 - SD



254023H9U



*(not for sale.)

缝纫组合件 表 (1)

GAUGE PARTS LIST (1)



形式 MACHINE TYPE /SEEC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE						
500-01CA 500-01CA/M	224	257517-24	257515A24	257206-16F	257258-16F	257460-24	257550E91	257553	257551B	25756S	UY128GAS #9						
	232	" 32	" 32			" 32											
	240	" 40	" 40			" 40											
	248	" 48	" 48			" 48											
	256	" 56	257517A56	257207-16F	257058-16F	" 56	257550-91				257553	257551B	25756S	UY128GAS #10			
	264	" 64	" 64			" 64											
	348	257518-48	257516A48			257206-16F									257258-16F	257461-48	257550E91
	356	" 56	257518A56			257207-16F									257259-16F	" 56	257550-91
364	" 64	" 64	" 64														
224	257517-24	257515B24	257206-16F	257258-16F	257460-24		257550E91	257553	257551B	25756S				UY128GAS #9			
232	" 32	" 32			" 32												
240	" 40	" 40			" 40												
248	" 48	" 48			" 48												
256	" 56	257517B56	257207-16F	257259-16F	" 56	257550-91	257553				257551B	25756S	UY128GAS #10				
264	" 64	" 64			" 64												
348	257518-48	257516B48			257206-16F									257258-16F	257461-48	257550E91	
356	" 56	257518B56			257207-16F									257259-16F	" 56	257550-91	
364	" 64	" 64	" 64														
224	257517-24	257515C24	257206-16F	257258-16F		257460-24		257550E91	257553	257551B			25756S		UY128GAS #9		
232	" 32	" 32				" 32											
240	" 40	" 40			" 40												
248	" 48	" 48			" 48												
256	" 56	257517C56	257207-16F	257259-16F	" 56	257550-91	257553	257551B			25756S	UY128GAS #10					
264	" 64	" 64			" 64												
348	257518-48	257516C48			257206-16F									257258-16F	257461-48	257550E91	
356	" 56	257518C56			257207-16F									257259-16F	" 56	257550-91	
364	" 64	" 64	" 64														
500-010DB 500-010DB/M	460	257513-60	257020-60	25723A-16F		257258-16F			257491-60	257550C91		257553	25755A		25756S	SM 1014B #3	
500-01GB 500-01GB/M	356	257518-56	257018B56	257207-16F		257259-16F			257472-56	257550-91		257553	257551B		25756S	UY128GAS #10	
	364	" 64	" 64		" 64												

缝纫组合件 表 (2)

GAUGE PARTS LIST (2)



形式 MACHINE TYPE /SECC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE	
500-02BA 500-02BA/M	224	257517-24	257029A24	257214-16F	257280-16F	257317A24	257550E91	257553	257551B	257565	UY128GAS #9	
	232	" 32	" 32			" 32						
	240	" 40	257030A40			257318A40						
	248	" 48	" 48			" 48						
	256	" 56	257032A56	257216-16F	257282-16F	257319A56	257550E91				257550-91	UY128GAS #10
	264	" 64	" 64			" 64						
	348	257518-48	257031A48			257320A48						
	356	" 56	257033A56			257321A56						
364	" 64	" 64	257216-16F	257282-16F	" 64	257550-91						
500-02BB 500-02BB/M	224	257517-24	257029B24	257214-16F	257280-16F	257317A24	257550E91	257553	257551B	257565	UY128GAS #9	
	232	" 32	" 32			" 32						
	240	" 40	257030B40			257318A40						
	248	" 48	" 48			" 48						
	256	" 56	257032B56	257216-16F	257282-16F	257319A56	257550E91				257550-91	UY128GAS #10
	264	" 64	" 64			" 64						
	348	257518-48	257031B48			257320A48						
	356	" 56	257033B56			257321A56						
364	" 64	" 64	257216-16F	257282-16F	" 64	257550-91						
500-02BC 500-02BC/M	224	257517-24	257029C24	257214-16F	257280-16F	257317A24	257550E91	257553	257551B	257565	UY128GAS #9	
	232	" 32	" 32			" 32						
	240	" 40	257030C40			257318A40						
	248	" 48	" 48			" 48						
	256	" 56	257032C56	257216-16F	257282-16F	257319A56	257550E91				257550-91	UY128GAS #10
	264	" 64	" 64			" 64						
	348	257518-48	257031C48			257320A48						
	356	" 56	257033C56			257321A56						
364	" 64	" 64	257216-16F	257282-16F	" 64	257550-91						

缝纫组合件 表 (3)

GAUGE PARTS LIST (3)



形式 MACHINE TYPE /SECC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-02SA 500-02SA/M	224	257517-24	257023A24	257208-16F	257261-16F	257350-24	257350E91	257553	257551B	25756S	UY128GAS #3
	232	" 32	" 32			" 32					
	240	" 40	257024A40	257210-16F	257202-16F	257351-40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257041A56	257210-16F	257262-16F	257358-56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257040A48	257209-16F	257261-16F	257359-48	257550E91				
	356	" 56	257025A56	257210-16F	257262-16F	257352-56	257550-91				
500-02SB 500-02SB/M	224	257517-24	257023B24	257208-16F	257260-16F	257350-24	257350E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257024B40	257209-16F	257261-16F	257351-40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257040B56	257210-16F	257262-16F	257358-56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257041B48	257209-16F	257261-16F	257359-48	257550E91				
	356	" 56	257025B56	257210-16F	257262-16F	257352-56	257550-91				
500-02SC 500-02SC/M	224	257517-24	257023C24	257208-16F	257260-16F	257350-24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257024C40	257209-16F	257261-16F	257351-40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257041C56	257210-16F	257262-16F	257358-56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257040C48	257209-16F	257261-16F	257359-48	257550E91				
	356	" 56	257025C56	257210-16F	257262-16F	257352-56	257550-91				
500-02CA 500-02CA/M	232	257139A32	257139A32	259123-16F	257260-16F	2572448-32	257550-91	257553	257551B	25756S	YU128GAS #10
500-02CB 500-02CB/M	240	257140A40	257140A40	259124-16F	257262-16F	257449-40		257553	257551B	25756S	YU128GAS #10
500-02CB 500-02CB/M	232	257139B32	257139A32	259123-16F	257260-16F	2572448-32		257553	257551B	25756S	YU128GAS #10
500-02CB 500-02CB/M	240	257140B40	257140A40	259124-16F	257261-16F	257449-40		257553	257551B	25756S	YU128GAS #10
500-02CC 500-02CC/M	232	257139C32	257139A32	259123-16F	257260-16F	2572448-32	257550-91	257553	257551B	25756S	YU128GAS #10
500-02CC 500-02CC/M	240	257140C40	257140A40	259124-16F	257261-16F	257449-40		257553	257551B	25756S	YU128GAS #10
500-02DB 500-02DB/M	232	257157B32	257157B32	259128-16F	259234-16F	257449-34	257550-91	257553	257551B	25756S	YU128GAS #10

缝纫组合件 表 (4)

GAUGE PARTS LIST (4)



形式 MACHINE TYPE /SECC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-02BA 500-02BA/M	240	257517-40	257087B40	257206-16F	259200-16F	257467-40		257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48					
	256	" 56	257089B56	257207-16F	259253-16F	" 56	257550-91				
	264	" 64	" 64			" 64					UY128GAS #10
	348	257518-48	257088B48	257206-16F	259200-16F	257468-48	257550E91				
	356	" 56	257090B56	257207-16F	259253-16F	" 56	257550-91				
500-02BB 500-02BB/M	240	257517-40	257087B40	257206-16F	259200-16F	257467-40		257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48					
	256	" 56	257089B56	257207-16F	259253-16F	" 56					
	264	" 64	" 64			" 64					UY128GAS #10
	348	257518-48	257088B48	257206-16F	259200-16F	257468-48	257550E91				
	356	" 56	257090B56	257207-16F	259253-16F	" 56	257550-91				
500-02BC 500-02BC/M	240	257517-40	257091B40	257206-16F	259201-16F	257467-40		257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257093B56	257207-16F	259254-16F	" 56					
	264	" 64	" 64			" 64					UY128GAS #10
	348	257518-48	257092B48	257206-16F	259201-16F	257468-48	257550E91				
	356	" 56	257094B56	257207-16F	259254-16F	" 56	257550-91				
500-02BC 500-02BC/M	240	257517-40	257091C40	257206-16F	259201-16F	257467-40		257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257093C56	257207-16F	259254-16F	" 56					
	264	" 64	" 64			" 64					UY128GAS #10
	348	257518-48	257092C48	257206-16F	259200-16F	257468-48	257550E91				
	356	" 56	257094C56	257207-16F	259254-16F	" 56	257550-91				

缝纫组合件 表 (5)

GAUGE PARTS LIST (5)

形式 MACHINE TYPE /SEEC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-05BA 500-05BA/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #3
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					
500-05BB 500-05BB/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					
500-05SA 500-05SA/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					
500-05SB 500-05SB/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					

缝纫组合件 表 (6)

GAUGE PARTS LIST (6)

形式 MACHINE TYPE /SEEC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-05CA 500-05CA/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					
500-05CB 500-05CB/M	224	257517-24	257049A24	257220-16F	257266-16F	257327A24	257550E91	257553	257551B	25756S	UY128GAS #9
	232	" 32	" 32			" 32					
	240	" 40	257050A40	257221-16F	257267-16F	257328A40					
	248	" 48	" 48			" 48	257550-91				
	256	" 56	257052A56	257222-16F	257268-16F	257329A56					UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257051A48	257221-16F	257267-16F	257330A48	257550E91				
	356	" 56	257053A56	257222-16F	257268-16F	257331A56					

缝纫组合件 表 (7)

GAUGE PARTS LIST (7)



形式 MACHINE TYPE /SECC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-06BA 500-06BA/M 500-07BA 500-07BA/M	232	257517-32	257044A32	257214-16F	257260-16F	257337A32	257550-91	257553	257551B	25756S	UY128GAS #9
	240	" 40	257045A40	257215-16F	257261-16F	257338A40					
	248	" 48	" 48			" 48					
	256	" 56	257047A56	257216-16F	257262-16F	257339A56	257550E91	257553	257551B	25756S	UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257046A48	257215-16F	257261-16F	257339A48					
	356	" 56	257048A56	257216-16F	257262-16F	257341A56	257550-91				
500-06BB 500-06BB/M 500-07BB 500-07BB/M	232	257517-32	257044B32	257214-16F	257260-16F	257337A32	257550-91	257553	257551B	25756S	UY128GAS #9
	240	" 40	257045B40	257215-16F	257261-16F	257338A40					
	248	" 48	" 48			" 48					
	256	" 56	257047B56	257216-16F	257262-16F	257339A56	257550E91	257553	257551B	25756S	UY128GAS #10
	264	" 64	" 64			" 64					
	348	257518-48	257046B48	257215-16F	257261-16F	257339A48					
	356	" 56	257048B56	257216-16F	257262-16F	257341A56	257550-91				
500-08AB 500-08AB/M	240	257517-40	257084B40	257206-16F	259209-16F	257480-40	257550-91	257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48					UY128GAS #10
	356	257518-56	257095B56	257207-16F	259210-16F	257461-56					UY128GAS #10
500-08AC 500-08AC/M	240	257517-40	257084C40	257206-16F	259209-16F	257160-48	257550-91	257553	257551B	25756S	UY128GAS #9
	248	" 48	" 48			" 48					UY128GAS #9
	256	257518-56	257095C56	257207-16F	259210-16F	257461-56					UY128GAS #10
	364	" 64	" 64			" 64					UY128GAS #10

缝纫组合件 表 (8)

GAUGE PARTS LIST (8)



形式 MACHINE TYPE /SECC.	缝样 GAUGE	针留 NEEDLE HOLDER	针板 NEEDLE PLATE	主送布牙 MAIN FEED DOG	差动送布牙 DIFF. FEED DOG	压脚 PRESSER FOOT	弯杆 LOOPER	护针(前) NEEDLE GUARD FRONT	护针(后) NEEDLE GUARD REAR	喂针 SPREADER	针 NEEDLE
500-21BA	356	257501C58	257022A58	257207-16F	257259-16F	257466-56	257550A91	257553	257551B	25756S	UY128GAS #10
500-21BA/M	364	" 64	" 64			" 64					UY128GAS #10
500-21BB	356	257501C56	257022B56	257207-16F	257259-16F	257466-56	257550A-91	257553	257551B	25756S	UY128GAS #10
500-21BB/M	364	" 64	" 64			" 64					UY128GAS #10
50082AB/M	224	257517-24	257119-24			257460-24	257550E91	257553	257551B	25756S	UY128GAS #10
	240	" 40	" 40	257206-16F	257223-16F	" 40					UY128GAS #10
	248	" 48	" 48			" 48					UY128GAS #10
	356	257518-56	257120-56	257207-16F	257224-16F	257461-56					UY128GAS #10
	364	" 64	" 64			" 64					UY128GAS #10

500N系列子型号规格表

500N系列



用途	子型号	针数 (根)	针数 (根)	针距(mm)	最大针 脚长 (mm)	差动比	压脚抬升量 (mm)	最高旋转数 (rpm)	备考
基本缝纫用	500-01CB	2 3	4 5	2.4・3.2・4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	
松紧带滚边用	500-02BB	2 3	4 5	2.4・3.2・4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	
棚盖缝用	500-03DB	2 3	4 5	4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	
	500-03EB	2 3	4 5	4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	
缝花边松紧带用	500-05CB	2 3	4 5	2.4・3.2・4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1	6.3 5	5,500 (MMD 5,000)	
	500-07BB	2 3	4 5	3.2・4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	5,000	
缝花边用	500-06BB	2 3	4 5	3.2・4・4.8・5.6・6.4 4.8・5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	
下摆折缝用	500-08AB	2 3	4 5	4・4.8 5.6・6.4	4.4	0.5~1.3	6.3 5	6,000	

※差动比使用1:1.3以上时, 请将主送布牙运动量设定在3.2mm以下。

针脚形式	602, 605
使用的针	UY128GAS #9S UY128GAS #10S
整机尺寸(WxDxH)	W: 495mm D: 2801mm H: 414mm

干燥时重量	41.5Kg
总重量	47.5Kg UY128GAS #10S
噪音值	n=5,400rpm: Lpas82.0dB DIN 45635 48A-1 遵循



零件名称 PART NAME	规格 SPEC.	数量 QTY	材料 MATERIAL	备注 REMARKS	零件名称 PART NAME	规格 SPEC.	数量 QTY	材料 MATERIAL	备注 REMARKS	零件名称 PART NAME	规格 SPEC.	数量 QTY	材料 MATERIAL	备注 REMARKS
500-05BA	2.5	100000	500-05BA		500-05BA	2.5	100000	500-05BA		500-05BA	2.5	100000	500-05BA	
500-05BA/M	2.5	100000	500-05BA/M		500-05BA/M	2.5	100000	500-05BA/M		500-05BA/M	2.5	100000	500-05BA/M	
500-07BA	2.5	100000	500-07BA		500-07BA	2.5	100000	500-07BA		500-07BA	2.5	100000	500-07BA	
500-07BA/M	2.5	100000	500-07BA/M		500-07BA/M	2.5	100000	500-07BA/M		500-07BA/M	2.5	100000	500-07BA/M	
500-05BB	2.5	100000	500-05BB		500-05BB	2.5	100000	500-05BB		500-05BB	2.5	100000	500-05BB	
500-05BB/M	2.5	100000	500-05BB/M		500-05BB/M	2.5	100000	500-05BB/M		500-05BB/M	2.5	100000	500-05BB/M	
500-07BB	2.5	100000	500-07BB		500-07BB	2.5	100000	500-07BB		500-07BB	2.5	100000	500-07BB	
500-07BB/M	2.5	100000	500-07BB/M		500-07BB/M	2.5	100000	500-07BB/M		500-07BB/M	2.5	100000	500-07BB/M	
500-05AB	2.5	100000	500-05AB		500-05AB	2.5	100000	500-05AB		500-05AB	2.5	100000	500-05AB	
500-05AB/M	2.5	100000	500-05AB/M		500-05AB/M	2.5	100000	500-05AB/M		500-05AB/M	2.5	100000	500-05AB/M	
500-05AC	2.5	100000	500-05AC		500-05AC	2.5	100000	500-05AC		500-05AC	2.5	100000	500-05AC	
500-05AC/M	2.5	100000	500-05AC/M		500-05AC/M	2.5	100000	500-05AC/M		500-05AC/M	2.5	100000	500-05AC/M	

Scan by zhuravli.pro
2022

浙江宝宇缝纫机股份有限公司
ZHEJIANG BAOYU SEWING MACHINE CO.,LTD.

中国浙江省台州市椒江区洪家街道经中路2299#
No.2299, Jingzhong Road, Hongjia Street, Jiaojiang, Taizhou, Zhejiang, China.


T. 0086-576-88159688 F. 0086-576-88159666
E. baoyu@chinabaoyu.com



www.chinabaoyu.com


节能伺服电机 Energy-Efficient Motors

电子使用手册 Electronic Manual Book



为了安全的使用,请您在使用之前一定阅读本使用说明书。
Please read the manual carefully before using this unit.
另外,请您注意保管本使用说明书,以便随时查阅。
Please keep this manual handy for ready reference.

系统界面连接和操作面板示意图如下:
Introduce for control panel



电机常用参数设置 Commonly used parameter setting

序号 The serial number	参数编号 Parameters name	参数名称 The parameters name	参数范围 Adjusting rang		出厂设置 The factory reset settings	备注 Remark
1	P-01	最大速度锁定 Maximum Speed lock	200-6500RPM		4500 转	
2	P-02	电机方向 Direction of rotation	0 是逆时针 0 is reverse turn needle	1 是顺时针 1 is clockwise turn	1	
3	P-04	起缝速度 Start sewing speed	200-800 转		250 转	
4	P-05	加速快慢 Speed up And slow	2000-4000 转		3000 转	
5	P-06	定针缝 Set the seam	0-999 针		0	
6	P-15	是否检测上针位 The location of the needle	1:检测针位, 0:不检测 1: detecting needle 0: no detection		1	

恢复出厂设置

恢复出厂设置方法: 先按“P”键不放, 同时按“+”号键, 此时画面会显示 P-00, 再长按“S”键约 3 秒即可。

Restore factory settings

Restore factory settings: Press the “P” key, no leave, and press the “+” key, the screen will display the P-00, then press “S” key 3 seconds.

更多参数请扫二维码获取





宝宇缝纫机

BAOYU Sewing machine

合格证

CERTIFICATE

型 号 MODEL	GT-500D-01
校 车 ADJUSTMENT	001
检验员 PASSED BY	检 5
机 号 MFG. NO	210307903